

TM57 系列

TM57ME20

使用慢速晶振时振荡口 设置说明

tenx reserves the right to change or discontinue the manual and online documentation to this product herein to improve reliability, function or design without further notice, tenx does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under its patent rights nor the rights of others, tenx products are not designed, intended, or authorized for use in life support appliances, devices, or systems. If Buyer purchases or uses tenx products for any such unintended or unauthorized application, Buyer shall indemnify and hold tenx and its officers, employees, subsidiaries, affiliates and distributors harmless against all claims, cost, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use even if such claim alleges that tenx was negligent regarding the design or manufacture of the part.

修改记录

| 版本 | 日期 | 描述 |
|------|-----------|----|
| V1.0 | May, 2013 | 新颁 |

CONTENTS

| 修改记录 | 2 |
|------------------|---|
| PRODUCT NAME | |
| TITLE | |
| APPLICATION NOTE | |

PRODUCT NAME

TM57 系列 IC

TITLE

AP_TM57ME20使用慢速晶振时振荡口设置说明

APPLICATION NOTE

TM57ME20 具有双时钟功能,在使用慢速晶振 SXT 时,对振荡输入口的设定与其它型号芯片的设置略有不同,TM57ME20 需要把 PA3、PA4 端口设置为使密特输入,且必须把上拉电阻关闭,否则慢速晶振 SXT 将无法起振。程序设定如下:

MAIN:

••

MOVLW XXX11XXXB

MOVWF PAD

MOVLW XXX00XXXB

MOVWR PAE

MOVLW XXX11XXXB

MOVWR nPAPU

;设 PA3、PA4 数据寄存器置 1

:设定 PA3、PA4 端口为使密特输入

;设定 PA3、PA4 端口上拉关闭

:其它程序

*注:"X"为用户自行设定值.